




Click or Scan this QR code to go to Gerber's Spec Sheet



## Hardware Requirements

To keep your Gerber software working at its peak performance, we recommend the following settings:

Gerber's Omega software runs on Windows computers only.

**Operating System:** Windows 10 Pro. - Enterprise and Ultimate are not recommended or supported.

**RAM:** 2 GB Minimum, 4 GB or more recommended

**Screen Resolution:** 1024x728 minimum, with 16 million colors.

**Free Hard Disk Space:** 40 GB Free

**DVD ROM Drive** to load the software

**Ports:** You will need compatible ports to connect to your devices. Legacy serial and parallel ports are not recommended. Gerber's USB to Parallel adapter for EDGE and EDGE2 printers and Gerber's USB to Serial adapter for GS, HS and EnVision plotters are supported by Denco and Gerber. Other brands may or may not work and are not supported by Denco or Gerber.

The EDGE FX and many third party plotters will run via Ethernet connection, so other ports may not be necessary.

Remember that these are only minimum recommendations. You will get better performance if you buy a faster computer with more memory and hard drive space than the minimums recommend.

Note: Internet connection required for updates and online support.

